



CHIMNEY EXTENSION INSTALLATION INSTRUCTIONS

How the chimney extension works (for models SU 1, SU 2, SU 3, SU 4, SU 5, SU 7, SU 22, SU 23, SU 26, SU 31, SU 36):

The lower duct cover is replaced with a 36" or 32" extension piece and is used to extend the height of the standard duct covers. The 36" or 32" lower duct cover piece is used for extending the standard duct cover, the completed installation will have two pieces, one 36" or 32" lower chimney and the upper chimney for the duct cover consisting of one joint (refer to figure 1 for measurements and product codes).

How the chimney extension works (for models SU103-9 & SU 202-14):

The extension of the standard chimney height is accomplished by adding an additional lower decorative chimneypiece to the standard configuration, which consists of the standard upper chimney section with vent slats in the one end and the standard lower chimney section. So before you start, ensure that there are two lower chimney sections and an upper chimney section. You will have to drill a few holes in the sides of the decorative chimneys towards the back of these. Do not remove the protective covering from the chimney sections until the following steps have been completed (refer to figure 1 for measurements and product codes).

Preparation:

Install the body of the hood as per the installation instructions. Measure the length of decorative chimney required from the body of the hood to where the decorative chimneys must end – this is normally at the ceiling, however if venting out the back wall, it is quite common to terminate the chimney midway up the wall. Find a perfectly flat, level and clean surface at least the length of the decorative chimney that is required. Please ensure that if the plastic has been removed from the chimney sections, a soft material is placed under the sections so as not to scratch the surface. Lay the decorative chimney sections out, end to end, with the section with grills in (the upper section) in the middle. All sections should have the inside facing up.

1. Insert the chimney section into the standard lower chimney section with the vent slats inside the lower chimney section – the vent slats are only required for a ductless installation and can therefore be "hidden" IF you have sufficient length of decorative chimney – if not, you will need to purchase an additional upper chimney section.
2. Slide the additional lower chimney section over the upper chimney section.



3. Now adjust the three pieces so that the length is equal to the overall length required for the decorative chimney. Ideally there should be three equal sections and the overlap of each section should be at least 1.5". Depending on the length required, the vent slats may be exposed or not. Adjust as required. Before proceeding to Step 4, ensure that when you look down the length of all three sections that they are perfectly straight. This is very important to ensure the decorative chimney when installed, is not curved.

4. Once satisfied that the length and line up is correct, drill a 1/8" hole on the sides, approximately 2" in from the edge that will be up against the wall, through both the additional lower chimney and the upper chimney section. Fit the appropriate metal screw through these drilled holes. The purpose of this is to restrict the upper chimney section from sliding down once the additional lower chimney section is fitted to the ceiling bracket.

5. The standard lower chimney section should not be fixed or worked on at all. You only need to 'join' the additional lower chimney section to the upper chimney section. The standard lower chimney section must be permitted to slide freely to allow installation.

6. Finally, using the ceiling mount bracket from the hardware kit as a template, drill two 1/8" holes that will line up with those at the end of the 'wings' on the ceiling mount bracket. This will enable you to attach the connected additional lower chimney section and the standard upper chimney section to the ceiling.

7. Now install the two chimney sections (the connected one and the standard lower one) as per the installation instructions.



Figure 1

Model	Std Min Height	Std Max Height	Max Height With Extension	Max Ceiling Height With Extension	Product Code
SU1	31"	44"	66"	132"	SU1 EXT36
SU2	28"	44"	58"	124"	SU2 EXT36
SU3	31"	44"	66"	132"	SU3 EXT36
SU4	31"	44"	66"	132"	SU4 EXT36
SU5	31"	44"	66"	132"	SU5 EXT36
SU7	28"	44"	58"	124"	SU7 EXT32
SU22	28"	44"	59"	125"	SU22 EXT32
SU23	28"	44"	59"	125"	SU23 EXT32
SU25	28"	44"	63"	129"	SU25 EXT36
SU26	28"	44"	63"	129"	SU26 EXT36
SU31	25"	41"	63"	129"	SU31 EXT36
SU36	25"	41"	63"	129"	SU36 EXT36
SU103	30"	46"	62"	128"	SU103 LX
SU202	30'	44"	60"	126"	SU202 LX